


Panels are Secured to the Wall directly to Selected Wall Battens.
Screw Fix through Face of Black Cross Members.



Two Fixing methods are provided for securing Panels to the Ceiling.
Option 1 is to Screw from inside ceiling cavity down in to rear of Black Cross Members.
Option 2 is to Screw up through Black Rails (between Blades) directly into ceiling system.